

# **BG95&BG77&BG600L Series**

## **FTM Application Note**

**LPWA Module Series**

Version: 1.1

Date: 2020-11-29

Status: Released



**Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:**

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local office. For more information, please visit:**

<http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm>

Or email to [support@quectel.com](mailto:support@quectel.com).

## **General Notes**

Quectel offers the information as a service to its customers. The information provided is based upon customers' requirements. Quectel makes every effort to ensure the quality of the information it makes available. Quectel does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information. All information supplied herein is subject to change without prior notice.

## **Disclaimer**

While Quectel has made efforts to ensure that the functions and features under development are free from errors, it is possible that these functions and features could contain errors, inaccuracies and omissions. Unless otherwise provided by valid agreement, Quectel makes no warranties of any kind, implied or express, with respect to the use of features and functions under development. To the maximum extent permitted by law, Quectel excludes all liability for any loss or damage suffered in connection with the use of the functions and features under development, regardless of whether such loss or damage may have been foreseeable.

## **Duty of Confidentiality**

The Receiving Party shall keep confidential all documentation and information provided by Quectel, except when the specific permission has been granted by Quectel. The Receiving Party shall not access or use Quectel's documentation and information for any purpose except as expressly provided herein. Furthermore, the Receiving Party shall not disclose any of the Quectel's documentation and information to any third party without the prior written consent by Quectel. For any noncompliance to the above requirements, unauthorized use, or other illegal or malicious use of the documentation and information, Quectel will reserve the right to take legal action.

## Copyright

The information contained here is proprietary technical information of Quectel Wireless Solutions Co., Ltd. Transmitting, reproducing, disseminating and editing this document as well as using the content without permission are forbidden. Offenders will be held liable for payment of damages. All rights are reserved in the event of a patent grant or registration of a utility model or design.

*Copyright © Quectel Wireless Solutions Co., Ltd. 2020. All rights reserved.*

# About the Document

## Revision History

Version	Date	Author	Description
1.0	2020-05-28	Hyman DING/ Miles MA	Initial
1.1	2020-11-29	Miles MA	<ol style="list-style-type: none"><li>1. Updated the uplink channel range for LTE B85 in AT+QRFTEST.</li><li>2. Added the applicability restrictions on LTE B26, B27 and B71 in AT+QRFTEST and AT+QRXFTM.</li></ol>

## Contents

About the Document .....	3
Contents .....	4
Table Index.....	5
<b>1 Introduction .....</b>	<b>6</b>
1.1. Applicable Modules .....	6
<b>2 FTM AT Commands .....</b>	<b>7</b>
2.1. AT Command Syntax .....	7
2.1.1. Definitions.....	7
2.1.2. AT Command Syntax .....	7
2.2. Description of FTM AT Commands.....	8
2.2.1. AT+QRFTESTMODE Enter/Exit FTM .....	8
2.2.2. AT+QRFTEST Transmit in FTM .....	9
2.2.3. AT+QRXFTM Receive in FTM.....	12
<b>3 Examples .....</b>	<b>15</b>
3.1. Set the Module into FTM.....	15
3.2. Transmit in FTM .....	15
3.3. Receive in FTM .....	18
<b>4 Appendix A References.....</b>	<b>19</b>

## Table Index

Table 1: Applicable Modules.....	6
Table 2: Type of AT Commands and Responses.....	7
Table 3: Terms and Abbreviations .....	19

# 1 Introduction

The document describes the AT commands which are used to test the receiving and transmitting performance of Quectel BG95 series, BG77 and BG600L-M3 modules under FTM (Factory Test Mode) so as to facilitate RF calibration.

## 1.1. Applicable Modules

Table 1: Applicable Modules

Module Series	Model	Description
<b>BG95</b>	BG95-M1	Cat M1 only
	BG95-M2	Cat M1/Cat NB2
	BG95-M3	Cat M1/Cat NB2/EGPRS
	BG95-M4	Cat M1/Cat NB2, 450 MHz Supported
	BG95-M5	Cat M1/Cat NB2/EGPRS, Power Class 3
	BG95-M6	Cat M1/Cat NB2, Power Class 3
	BG95-MF	Cat M1/Cat NB2, Wi-Fi Positioning
<b>BG77</b>	BG77	Cat M1/Cat NB2
<b>BG600L</b>	BG600L-M3	Cat M1/Cat NB2/EGPRS

### NOTE

See the firmware release notes of corresponding module models to check whether the function has been supported.

# 2 FTM AT Commands

## 2.1. AT Command Syntax

### 2.1.1. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on command line. When an optional parameter is omitted, the new value equals its previous value or its default setting, unless otherwise specified.
- **Underline** Default setting of a parameter.

### 2.1.2. AT Command Syntax

The **AT** or **at** prefix must be added at the beginning of each command line. Entering **<CR>** will terminate a command line. Commands are usually followed by a response that includes **<CR><LF><response><CR><LF>**. Throughout this document, only the response **<response>** will be presented, **<CR><LF>** are omitted intentionally.

**Table 2: Type of AT Commands and Responses**

<b>Test Command</b>	<b>AT+&lt;cmd&gt;=?</b>	This command returns the list of parameters and value ranges set by the corresponding Write Command or internal processes.
<b>Read Command</b>	<b>AT+&lt;cmd&gt;?</b>	This command returns the currently set value of the parameter or parameters.
<b>Write Command</b>	<b>AT+&lt;cmd&gt;=&lt;p1&gt; [,&lt;p2&gt;[,&lt;p3&gt;[...]]]</b>	This command sets the user-definable parameter values.
<b>Execution Command</b>	<b>AT+&lt;cmd&gt;</b>	This command reads non-variable parameters affected by internal processes in the module.



## 2.2. Description of FTM AT Commands

### 2.2.1. AT+QRFTESTMODE Enter/Exit FTM

The Write Command makes the module enter/exit FTM (RF test mode).

**AT+QRFTEST** (see *Chapter 2.2.2*) and **AT+QRXFTM** (see *Chapter 2.2.3*) are available only when the module enters FTM with this command.

#### AT+QRFTESTMODE Enter/Exit FTM

Test Command <b>AT+QRFTESTMODE=?</b>	Response <b>+QRFTESTMODE:</b> (list of supported <mode>s)  <b>OK</b>
Read Command <b>AT+QRFTESTMODE?</b>	Response <b>+QRFTESTMODE:</b> <mode>  <b>OK</b>
Write Command <b>AT+QRFTESTMODE=&lt;mode&gt;</b>	Response <b>OK</b>  If there is any error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  If there is any other error: <b>ERROR</b>
Characteristics	The command takes effect immediately. The configuration is saved automatically.

#### Parameter

<mode>	Integer type. Enter/exit FTM.
0	Exit FTM
1	Enter FTM

## 2.2.2. AT+QRFTEST Transmit in FTM

The Write Commands force the module to transmit in FTM.

<b>AT+QRFTEST Transmit in FTM</b>	
<p>Test Command</p> <p>The command currently only returns the list of parameters set by the Write Command in GSM</p> <p><b>AT+QRFTEST=?</b></p>	<p>Response</p> <p><b>+QRFTEST: &lt;band&gt;,&lt;channel&gt;,&lt;tx_enable&gt;,&lt;tx_burst&gt;,&lt;tx_gain&gt;</b></p> <p><b>OK</b></p>
<p>Write Command</p> <p>In GSM:</p> <p><b>AT+QRFTEST=&lt;band&gt;,&lt;channel&gt;,&lt;tx_enable&gt;,&lt;tx_burst&gt;,&lt;tx_gain&gt;</b></p>	<p>Response</p> <p><b>ALL ON</b></p> <p><b>OK</b></p> <p>Or</p> <p><b>ALL OFF</b></p> <p><b>OK</b></p> <p>If there is any error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>If there is any other error: <b>ERROR</b></p>
<p>Write Command</p> <p>In LTE-M:</p> <p><b>AT+QRFTEST=&lt;band&gt;,&lt;channel&gt;,&lt;tx_enable&gt;,&lt;rgi&gt;,&lt;waveform&gt;</b></p>	<p>Response</p> <p><b>ALL ON</b></p> <p><b>OK</b></p> <p>Or</p> <p><b>ALL OFF</b></p> <p><b>OK</b></p> <p>If there is any error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>If there is any other error: <b>ERROR</b></p>
<p>Write Command</p> <p>In NB-IoT:</p> <p><b>AT+QRFTEST=&lt;band&gt;,&lt;channel&gt;,&lt;tx_enable&gt;,&lt;rgi&gt;,&lt;waveform&gt;,&lt;ul_offset&gt;,&lt;mod_type&gt;,&lt;power&gt;,&lt;tone_bw&gt;,&lt;tone_idx&gt;</b></p>	<p>Response</p> <p><b>ALL ON</b></p> <p><b>OK</b></p> <p>Or</p>

	<p><b>ALL OFF</b></p> <p><b>OK</b> If there is any error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>If there is any other error: <b>ERROR</b></p>
Characteristics	<p>The command takes effect immediately. The configurations is not saved.</p>

## Parameter

<b>&lt;band&gt;</b>	<p>String type. Supported bands in GSM/LTE. The possible values are:</p> <p><b>For GSM:</b> "GSM850" "GSM900" "GSM1800" "GSM1900"</p> <p><b>For LTE:</b> "LTE BAND1" "LTE BAND2" "LTE BAND3" "LTE BAND4" "LTE BAND5" "LTE BAND8" "LTE BAND12" "LTE BAND13" "LTE BAND18" "LTE BAND19" "LTE BAND20" "LTE BAND25" "LTE BAND26" (Supported by LTE-M only) "LTE BAND27" (Supported by LTE-M only) "LTE BAND28" "LTE BAND31" (Supported by BG95-M4 only) "LTE BAND66" "LTE BAND71" (Supported by NB-IoT only) "LTE BAND72" (Supported by BG95-M4 only) "LTE BAND73" (Supported by BG95-M4 only) "LTE BAND85"</p>
<b>&lt;channel&gt;</b>	<p>Integer type. Supported uplink channels in GSM/LTE. The corresponding channels for different bands in GSM/LTE are as follows:</p>

---

**GSM band                      Uplink Channels**

GSM850	128–251
GSM900	1–124, 975–1023
GSM1800	512–885
GSM1900	512–810

**LTE band                      Uplink Channels**

LTE BAND1	18000–18599
LTE BAND2	18600–19199
LTE BAND3	19200–19949
LTE BAND4	19950–20399
LTE BAND5	20400–20649
LTE BAND8	21450–21799
LTE BAND12	23010–23179
LTE BAND13	23180–23279
LTE BAND18	23850–23999
LTE BAND19	24000–24149
LTE BAND20	24150–24449
LTE BAND25	26040–26689
LTE BAND26	26690–27039 (Supported by LTE-M only)
LTE BAND27	27040–27209 (Supported by LTE-M only)
LTE BAND28	27210–27659
LTE BAND31	27760–27809 (Supported by BG95-M4 only)
LTE BAND66	131972–132671
LTE BAND71	131122–133471 (Supported by NB-IoT only)
LTE BAND72	133472–133521 (Supported by BG95-M4 only)
LTE BAND73	133522–133571 (Supported by BG95-M4 only)
LTE BAND85	134002–134181

<b>&lt;tx_enable&gt;</b>	String type. Enable/disable RF TX. "ON"    Enable RF TX "OFF"   Disable RF TX
<b>&lt;tx_burst&gt;</b>	Integer type. 0    Continuous TX mode
<b>&lt;tx_gain&gt;</b>	Integer type. GSM power level (GSM power in dBm × 100). Range: 0–3300.
<b>&lt;rgi&gt;</b>	Integer type. LTE power level. Range: 0–100.
<b>&lt;waveform&gt;</b>	Integer type. 1    LTE modulated TX mode
<b>&lt;ul_offset&gt;</b>	Integer type. Uplink carrier frequency offset. Range: -128 to 127.
<b>&lt;mod_type&gt;</b>	Integer type. Modulation type. 0    BPSK 1    QPSK
<b>&lt;power&gt;</b>	Integer type. TX power in dBm. Range: -128 to 127.
<b>&lt;tone_bw&gt;</b>	Integer type. Uplink tone bandwidth. 0    Single-tone, 3.75 kHz

---

- 1 Single-tone, 15 kHz
- 2 Multi-tone, 3 × 15 kHz
- 3 Multi-tone, 6 × 15 kHz
- 4 Multi-tone, 12 × 15 kHz

**<tone\_idx>** Integer type. Tone start index. Range: 0–255.

## NOTES

- Please refer to **Section 5.7.3F Carrier frequency and EARFCN for category NB1 and NB2** in *3GPP TS 36.101*, to calculate the specific uplink carrier frequency offset, namely, the value of **<ul\_offset>**.
- For LTE-M, the default bandwidth is 10 MHz currently.

### 2.2.3. AT+QRXFTM Receive in FTM

The Write Command forces the module to receive in FTM.

#### AT+QRXFTM Receive in FTM

Test Command <b>AT+QRXFTM=?</b>	Response <b>+QRXFTM: &lt;mode&gt;,&lt;band&gt;,&lt;channel&gt;,&lt;path&gt;,&lt;lna&gt;,&lt;bw&gt;</b>  <b>OK</b>
Read Command <b>AT+QRXFTM?</b>	Response <b>OK</b>
Write Command <b>AT+QRXFTM=&lt;mode&gt;,&lt;band&gt;,&lt;channel&gt;[,&lt;path&gt;[,&lt;lna&gt;[,&lt;bw&gt;]]]</b>	Response <b>+QRXFTM: &lt;agc_val&gt;,&lt;agc_to_pwr&gt;</b>  <b>OK</b>  If there is any error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  If there is any other error: <b>ERROR</b>
Characteristics	The command takes effect immediately. The configurations is not saved.

#### Parameter

**<mode>** Integer type.  
1 LTE RX test

**<band>** String type. Supported bands in GSM/LTE. The possible values are:

**For GSM:**

"GSM850"  
"GSM900"  
"GSM1800"  
"GSM1900"

**For LTE:**

"LTE BAND1"  
"LTE BAND2"  
"LTE BAND3"  
"LTE BAND4"  
"LTE BAND5"  
"LTE BAND8"  
"LTE BAND12"  
"LTE BAND13"  
"LTE BAND18"  
"LTE BAND19"  
"LTE BAND20"  
"LTE BAND25"  
"LTE BAND26" (Supported by LTE-M only)  
"LTE BAND27" (Supported by LTE-M only)  
"LTE BAND28"  
"LTE BAND31" (Supported by BG95-M4 only)  
"LTE BAND66"  
"LTE BAND71" (Supported by NB-IoT only)  
"LTE BAND72" (Supported by BG95-M4 only)  
"LTE BAND73" (Supported by BG95-M4 only)  
"LTE BAND85"

**<channel>** Integer type. Supported downlink channels in GSM/LTE. The corresponding channels for different bands in GSM/LTE are as follows:

**GSM band                      Downlink Channels**

GSM850	128–251
GSM900	1–124, 975–1023
GSM1800	512–885
GSM1900	512–810

**LTE band                      Downlink Channels**

LTE BAND1	0–599
LTE BAND2	600–1199
LTE BAND3	1200–1949
LTE BAND4	1950–2399
LTE BAND5	2400–2649
LTE BAND8	3450–3799

---

LTE BAND12	5010–5179
LTE BAND13	5180–5279
LTE BAND18	5850–5999
LTE BAND19	6000–6149
LTE BAND20	6150–6449
LTE BAND25	8040–8689
LTE BAND26	8690–9039 (Supported by LTE-M only)
LTE BAND27	9040–9209 (Supported by LTE-M only)
LTE BAND28	9210–9659
LTE BAND31	9870–9919 (Supported by BG95-M4 only)
LTE BAND66	66436–67335
LTE BAND71	68586–68935 (Supported by NB-IoT only)
LTE BAND72	68936–68985 (Supported by BG95-M4 only)
LTE BAND73	68986–69035 (Supported by BG95-M4 only)
LTE BAND85	70366–70545

<b>&lt;path&gt;</b>	Integer type. <u>0</u> Main antenna path.
<b>&lt;lna&gt;</b>	Integer type. Gain stages. Range: <u>0</u> –5.
<b>&lt;bw&gt;</b>	Integer type. Bandwidth. Range: <u>0</u> –5. This parameter is only valid for LTE RAT (that is, not applicable for GSM RAT). <u>0</u> 1.4 MHz bandwidth 1 3 MHz bandwidth 2 5 MHz bandwidth 3 10 MHz bandwidth 4 15 MHz bandwidth 5 20 MHz bandwidth
<b>&lt;agc_val&gt;</b>	Integer type. Result of receiving power range.
<b>&lt;agc_to_pwr&gt;</b>	Integer type. Receiving power level in dBm converted from <b>&lt;agc_val&gt;</b> .

---

## NOTES

1. The result of **AT+QRXFTM** is an instantaneous value.
2. In LTE RAT, the value of **<agc\_to\_pwr>** equals to **<agc\_val>** / 10.

# 3 Examples

## 3.1. Set the Module into FTM

```
AT+QRFTESTMODE=?           //Test command
+QRFTESTMODE: (0,1)

OK
AT+QRFTESTMODE=1           //Enter FTM
OK
AT+QRFTESTMODE?           //Query the current FTM state of the module
+QRFTESTMODE: 1

OK
AT+QRFTESTMODE=0           //Exit FTM
OK
AT+QRFTESTMODE?           //Query the current FTM state of the module
+QRFTESTMODE: 0

OK
```

## 3.2. Transmit in FTM

```
AT+QRFTESTMODE=1           //Enter FTM
OK

//In GSM RAT
AT+QRFTEST="GSM900",122,"ON",0,100 //Enable RF TX on 122 channel of GSM900
ALL ON

OK
AT+QRFTEST="GSM900",122,"OFF",0,100 //Disable RF TX on 122 channel of GSM900
ALL OFF

OK
```



//In LTE-M RAT

**AT+QRFTEST="LTE BAND1",18300,"ON",50,1** //Enable RF TX on 18300 channel of LTE B1  
**ALL ON**

OK

**AT+QRFTEST="LTE BAND1",18300,"OFF",50,1** //Disable RF TX on 18300 channel of LTE B1  
**ALL OFF**

OK

**AT+QRFTEST="LTE BAND2",18900,"ON",50,1** //Enable RF TX on 18900 channel of LTE B2  
**ALL ON**

OK

**AT+QRFTEST="LTE BAND2",18900,"OFF",50,1** //Disable RF TX on 18900 channel of LTE B2  
**ALL OFF**

OK

**AT+QRFTEST="LTE BAND12",23095,"ON",50,1** //Enable RF TX on 23095 channel of LTE B12  
**ALL ON**

OK

**AT+QRFTEST="LTE BAND12",23095,"OFF",50,1** //Disable RF TX on 23095 channel of LTE B12  
**ALL OFF**

OK

**AT+QRFTEST="LTE BAND20",24300,"ON",50,1** //Enable RF TX on 24300 channel of LTE B20  
**ALL ON**

OK

**AT+QRFTEST="LTE BAND20",24300,"OFF",50,1** //Disable RF TX on 24300 channel of LTE B20  
**ALL OFF**

OK

**AT+QRFTEST="LTE BAND28",27435,"ON",50,1** //Enable RF TX on 27435 channel of LTE B28  
**ALL ON**

OK

**AT+QRFTEST="LTE BAND28",27435,"OFF",50,1** //Disable RF TX on 27435 channel of LTE B28  
**ALL OFF**

OK

//In NB-IoT RAT

**AT+QRFTEST="LTE BAND1",18300,"ON",50,1,100,0,50,4,0** //Enable RF TX on 18300 channel of

ALL ON	LTE B1
OK	
<b>AT+QRFTEST="LTE BAND1",18300,"OFF",50,1,100,0,50,4,0</b>	//Disable RF TX on 18300 channel of LTE B1
ALL OFF	
OK	
<b>AT+QRFTEST="LTE BAND2",18900,"ON",50,1,100,0,50,4,0</b>	//Enable RF TX on 18900 channel of LTE B2
ALL ON	
OK	
<b>AT+QRFTEST="LTE BAND2",18900,"OFF",50,1,100,0,50,4,0</b>	//Disable RF TX on 18900 channel of LTE B2
ALL OFF	
OK	
<b>AT+QRFTEST="LTE BAND20",24300,"ON",50,1,100,0,50,4,0</b>	//Enable RF TX on 24300 channel of LTE B20
ALL ON	
OK	
<b>AT+QRFTEST="LTE BAND20",24300,"OFF",50,1,100,0,50,4,0</b>	//Disable RF TX on 24300 channel of LTE B20
ALL OFF	
OK	
<b>AT+QRFTEST="LTE BAND28",27435,"ON",50,1,100,0,50,4,0</b>	//Enable RF TX on 27435 channel of LTE B28
ALL ON	
OK	
<b>AT+QRFTEST="LTE BAND28",27435,"OFF",50,1,100,0,50,4,0</b>	//Disable RF TX on 27435 channel of LTE B28
ALL OFF	
OK	
<b>AT+QRFTESTMODE=0</b>	//Disable RF test mode
OK	

### 3.3. Receive in FTM

```
AT+QRFTESTMODE=1 //Enter FTM
OK

//In LTE RAT
AT+QRXFTM=1,"LTE BAND1",300,0,0,0 //Enable RF RX on 300 channel of LTE B1
+QRXFTM: -1100,-110

OK
AT+QRXFTM=1,"LTE BAND2",900,0,0,0 //Enable RF RX on 900 channel of LTE B2
+QRXFTM: -1100,-110

OK
AT+QRXFTM=1,"LTE BAND12",5095,0,0,0 //Enable RF RX on 5095 channel of LTE B12
+QRXFTM: -1100,-110

OK
AT+QRXFTM=1,"LTE BAND20",6300,0,0,0 //Enable RF RX on 6300 channel of LTE B20
+QRXFTM: -1100, -110

OK
AT+QRXFTM=1,"LTE BAND28",9435,0,0,0 //Enable RF RX on 9435 channel of LTE B28
+QRXFTM: -1100,-110

OK

//In GSM RAT
AT+QRXFTM=1,"GSM900",62,0,0 //Enable RF RX on 62 channel of GSM900
+QRXFTM: 3101799,-90

OK
AT+QRFTESTMODE=0 //Exit FTM
OK
```

# 4 Appendix A References

**Table 3: Terms and Abbreviations**

Abbreviation	Description
BPSK	Binary Phase Shift Keying
LTE-M	LTE-MTC (Machine Type Communication)
FTM	Factory Test Mode
GSM	Global System for Mobile Communications
LPWA	Low-Power Wide-Area
LTE	Long Term Evolution
NB-IoT	Narrow Band Internet of Things
QPSK	Quadrature Phase Shift Keying
RAT	Radio Access Technology
RF	Radio Frequency
RX	Receive
TX	Transmit