



Flow Switch for Water Tower & Tank. (Use with LSn50)



Flow Sensor working status. The





Same as door sensor, when PB14 and VDD connected (flow switch close) there will be rise edge, if the PB14 and VDD disconnected (flow switch open) there will be a falling edge.

